

## WALL MOUNTING INSTRUCTIONS:

- 1) **SOFT FRAMED MIRRORS (WITH WOOD BACKBOARD)**
- 2) **UNFRAMED MIRRORS**


All Spaces4Kids mirrors must be mounted on a wall. All mirrors are supplied with protective transit film on the front, remove this to reveal the mirror. Completely remove film temporarily BEFORE permanently mounting the mirror on the wall to check mirrored surface is intact, REPLACE the transit film temporarily to protect the mirror during wall mounting. **GLUING MIRRORS TO A WALL: THIS IS OFTEN THE MOST CONVENIENT WAY TO MOUNT YOUR MIRROR. NOTE THAT ADHESIVE PRODUCTS MAY DAMAGE PLASTER OR PAPER WALL COVERINGS ETC. ESPECIALLY ON REMOVAL. SELF ADHESIVE FIXINGS WILL NOT WORK WELL IN DAMP/OUTDOOR CONDITIONS. SCREWS (NOT SUPPLIED) WITH PROPRIETARY MIRROR FIXINGS AVAILABLE FROM MOST DIY RETAILERS CAN ALSO BE USED. DAMAGE/BREAKS CAUSED BY CONSTANT BENDING OR CRUSHING ARE NOT COVERED BY THE GUARANTEE.**

- 1). **INSTRUCTIONS FOR SOFT FRAMED MIRRORS (WOOD BACKBOARD):** ONLY FOR USE INDOORS, NOT FOR OUTDOOR USE.

TO WALL MOUNT: PLACE AT A HEIGHT FROM THE FLOOR SUCH THAT CHILDREN DO NOT HANG OFF OR PULL ON THE FRAME.

SEVERE PULLING OF THE FRAME MAY RESULT IN THE FRAME BEING DETACHED FROM THE WOODEN BACK BOARD.

- a) Apply adhesive directly onto the backboard (e.g. No More Nails – not supplied) and mount on a wall, or
- b) Use Brass Wall Plates (supplied with small backboard screws) (other Wall fixings not supplied.)



- 2). **INSTRUCTIONS FOR UNFRAMED MIRRORS (NO BACKBOARD) INDOOR & OUTDOOR USE:** Decorative stickers where supplied are for indoor use only.

**Indoor Use:** mount onto wall with sticky pad fixings (you may need to supplement the supply provided). Alternative methods; i) double sided tape (not supplied); ii) adhesive (e.g. No More Nails – not supplied); iii) wall screws (not supplied - drill mirror and fix with proprietary mirror fixing kits available from DIY outlets.)

